


AR02

GP ReCyko⁺

新一代環保充電電池

標準充電器

說明書



充電時間

GP ReCyko ⁺			時間(小時)
鎳氫 (NiMH)	AA	2050 mAh	~10
	AAA	820 mAh	~10

- GP ReCyko⁺ 新一代環保充電電池，於出廠前經已充電，故首次使用毋須充電，可以即買即用。
- GP ReCyko⁺ 新一代環保充電電池，儲電力強，充電完畢後請即將電池取出，切勿將GP ReCyko⁺ 放於充電器內長時間充電。當不使用充電器時，請把充電器與電源分開。

規格

插頭	輸入電壓 (伏)	輸出電壓 (伏)	充電電流 (mA)	
			AA	AAA
BS (香港)	AC 230V	DC 1.4V	220	100
UL (台灣)	AC 120V			

07070K07235

GP ReCyko⁺ 新一代環保充電電池特點：

- 儲電力強，一年後仍可保留約85%電力
- 即買即用，首次使用毋須充電，隨時可用
- 適用於所有電子產品

請於使用前詳細閱讀此說明書，並保留作參考。

操作提示：

- 將GP ReCyko⁺ 充電器接上電源，避免使用拖板 / 延長插座。
- 每次可為1或2粒AA/AAA GP ReCyko⁺ 新一代環保鎳氫(NiMH)充電電池充電。
- 把GP ReCyko⁺ 新一代環保鎳氫(NiMH)充電電池按照正負(+/-)極正確位置放入GP ReCyko⁺ 充電器內，以免倒充。
- 充電進行時，綠色LED燈會持續亮起直至將GP ReCyko⁺ 充電器與電源分離或取出電池，LED燈才會熄滅。

為達至最佳充電效果及安全保障，必須將GP ReCyko⁺ 充電器 / GP 超霸充電寶與GP ReCyko⁺ 新一代環保鎳氫(NiMH)充電電池配合使用。

注意事項：

- GP ReCyko⁺ 充電器只供於室內環境使用，切勿將其置於下雨、下雪，或其他惡劣的環境中。
- GP ReCyko⁺ 充電器只可為鎳氫(NiMH)充電電池充電。切勿使用GP ReCyko⁺ 充電器為其他種類電池(例如鹼性電池、鹼性充電電池、碳鋅電池、鋰電池，以及未有列出的其他類別電池)充電，因可能會引起電池漏液或爆裂，導致受傷。
- 切勿將新及用過的電池、不同類型(如鹼性、碳性、鋰電池、鹼性充電電池及其他沒有列出的電池)或品牌的電池一起使用，因可能會引起電池漏液或爆裂，導致受傷。
- 電子產品如長時間不用，請把充電電池取出。
- 切勿沾濕、燃燒、拆解GP ReCyko⁺ 充電器及充電電池。
- 切勿將同一粒電池的正負(+/-)極連接。
- 若充電電池效能明顯下降，請更換充電電池。
- 必須將此GP ReCyko⁺ 充電器垂直或水平地連接電源。
- 充電電池儲存溫度：-20 至30
充電器操作溫度：0 至45

於香港購買憑發票保用1年


(香港) 查詢熱線：(852) 2420 0281 (台灣) 查詢熱線：(886) 2 8792 1961

AR02

GP ReCyko⁺

NEW GENERATION RECHARGEABLE BATTERY

Instruction Manual



Charging Time

GP ReCyko ⁺			Hour
Typical Capacity	AA	2050mAh	~10
	AAA	820mAh	~10

- GP ReCyko⁺ batteries do not require a recharge prior to first use. They are charged before shipped.
- GP ReCyko⁺ batteries come with good capacity retention. Remove the batteries and unplug the charger once the charging is complete. Do not leave batteries in the charger for extended periods. Always unplug the charger when it is not in use.

Specifications

Plug	Input Voltage	Output Voltage	Charging Current	
			AA	AAA
BS(HK)	AC 230V	DC 1.4V	220	100
UL(TW)	AC 120V			

1009K09295

GP ReCyko⁺ Battery Features :

- Good Capacity Retention
- Ready to use
- Good for all applications

Read the instruction manual thoroughly before use. Keep the manual for future reference.

Charging Instructions :

- Connect GP ReCyko⁺ charger directly to a power source. Never use extension cords.
- Charge only GP ReCyko⁺ batteries in GP ReCyko⁺ charger. Both AA and AAA size batteries can be charged at the same time.
- Insert GP ReCyko⁺ batteries into GP ReCyko⁺ charger according to the battery polarity. Avoid reverse charging.
- Do not charge same size batteries of different capacities at the same time.
- The green LED indicators will remain on during charging. Only when the charger is unplugged or the batteries are removed, the indicators will switch off.

For best performance and optimal safety, charge GP ReCyko⁺ Batteries with GP ReCyko⁺ Charger / GP PowerBank.

Important :

- GP ReCyko⁺ charger is designed for indoor use only. Do not expose it to rain or snow.
- Charge only NiMH type rechargeable batteries. Do not charge non-rechargeable batteries. Other types of batteries may burst causing personal injury and damage.
- Do not mix different types of batteries (eg. NiMH, NiCd, alkaline, etc) in the electrical device.
- Remove batteries from the electrical device if the device is not going to be used for a long time.
- Do not incinerate, disassemble or short circuit batteries.
- If the performance of the batteries decrease substantially, it is time to replace the batteries.
- This direct plug-in power unit shall be correctly orientated in a vertical or floor mount position.
- Charging temperature: 0 - 45°C ;
Battery storage temperature: -20 - 30°C

1 year warranty with a receipt for purchase in Hong Kong
Enquiry Hotline : (852) 2420 0281 (Hong Kong)
(886) 2 8792 1961 (Taiwan)